

INSTRUCTION MANUAL



Micro Tweezers

Ref. PA120-A

Packing List


The following items are included:






PA120-A Changing cartridges

1. Unlocking



Unlock the fixing screws.

2. Removing




Place the cartridges in the extractor and pull the tweezers to remove them.

3. Inserting



Use the grooves to insert the cartridges as far as the mark*.


4. Locking





Lock the fixing screws.

Compatible cartridges

The PA120-A works with C120 cartridge range. Find the model that best suits your soldering needs in www.jbctools.com







Chisel Bent

Specifications

- Maximum power per cartridge 40W

- Tool Dimensions / Weight 78 x 33 x 25 mm / 0.10 kg. $3.07 \times 1.30 \times 0.98 \text{ in } / 0.22 \text{ lb.}$ $(L \times W \times H)$

- Total Package Dimensions / Weight 277 x 73 x 50 mm / 0.17 kg. $(L \times W \times H)$ 10.91 x 2.87 x 1.97 in / 0.36 lb.

ESD Safe



Warranty

JBC's 2 year warranty covers this equipment against all manufacturing defects, including the replacement of defective parts and labour.

Warranty does not cover product wear or misuse. In order for the warranty to be valid, equipment must be returned, postage paid, to the dealer where it was purchased.



This product should not be thrown in the garbage.

In accordance with the European directive 2012/19/EU, electronic equipment at the end of its life must be collected and returned to an authorized recycling facility.



