

Software Updater

User Manual

JBC Stations Updater version: U016700

MORE INFORMATION AT www.jbctools.com

Content

Introduction	4
System requirements	4
NET Framework 4.5.1	4
Download and install NET Framework 4.5.1	4
Compatible Stations	5
Install and Unistall	6
Program Description	6

Introduction

With this program you can update the Software of all the JBC stations that can be connected through a USB A-B cable.

System requirements

 $\ensuremath{\textbf{OS:}}$ Windows 7 / 8 / 8.1 / 10 with NET Framework 4.5.1

Processor: Intel i3 (Minimum)

RAM: 1GB(Minimum), 2GB (Recommended)

Hard Disk: 50 MB of available space

NET Framework 4.5.1

Compatible OS

Windows 7 Service Pack 1

Windows 8

Windows 10

Download and install NET Framework 4.5.1

Microsoft NET Framework 4.5.1 (Web Installer), Internet connection is required.

Microsoft NET Framework 4.5.1 (Standalone Installer)

Compatible Stations

The following list shows the JBC stations that are compatible with the JBC Updater application as well as the required version of the program.

Station	Minimum version
DM	9996649
DD	9996650
DDR	9996771
DI	9996822
HD	9996652
HDR	9996772
CD/CF	9996653
CS/CV	9996654
СР	9996655
NA	9996656
JTE-B	9996695
JTE-D	9996976
SF	All versions
FAE	All versions
PH-B	9996816
PH-S	9996816

Install and Uninstall

To **install** the program execute the program installer and follow installer assistant steps. The installation program will create a desktop shortcut and a folder in the Programs menu.

To **uninstall** the program execute the option "Uninstall" on the JBC folder in the Starting menu.

Program Description

Connect the station trough a USB A-B cable to the computer and Start the program. Restart the station and the program will list all the stions connected. The program will show which stations are updated, which are not updatable and wich have an update available.

JBC JBC S	Stations Updater			_ _ X
	Station	Program version	Available program version	Station status
	NAE [NAE]	8886260		Not updateable
	SF_LCD_01 [SF]	8886129	8886147	Update available
	No name [F2]	8886252	8886252	Updated
	DME 1 [DME]	8886266		Not updateable
				Update
,	www.jbctools.com			Copyright 2018 JBC Company ®

In order to update the station, the check box of the station has to be marked and press the update button. It is possible to update more than one station at a time.

During the update process a progress bar will show the status. Do not disconnect, turn off the station or close the program during this process.

JBC St	tations Updater			– – X	
	Station	Program version	Available program version	Station status	
	NAE [NAE]	8886260		Not updateable	
V	SF_LCD_01 [SF]	8886129	8886147	49%	
	No name [F2]	8886252	8886252	Updated	
	DME 1 [DME]	8886266		Not updateable	
Updating, please do not disconnect the stations. This process can take several minutes					
w	ww.jbctools.com			(

Once the update is finished, the station will restart itself automatically and will be shown as disconnected for few seconds.

JBC Stations Updater			
Station	Program version	Available program version	Station status
NAE [NAE]	8886260		Not updateable
SF_LCD_01 [SF]	8886129	8886147	Disconnected
No name [F2]	8886252	8886252	Updated
DME 1 [DME]	8886266		Not updateable
			Update
www.jbctools.com			Copyright 2018 JBC Company ®